



PRODUCT CARE

How to care for your Clarus product.

ERASING AND CLEANING

Clarus products are compatible with any marker. Dry erase and paint markers can be wiped off using a simple eraser or dry cloth. Permanent markers may be removed using any standard glass cleaner.

Periodic cleaning of your Clarus product may be performed using glass cleaner on the front side of the board. Surround frames can be wiped clean with a cloth, or mild soap and water as needed.

MARKER SELECTION

You may use any type of writing instrument, including but not limited to: permanent markers, chalk/grease markers, neon markers or dry erase marker. For a premium writing experience, Clarus offers a collection of recommended markers at clarus.com/shop. Please call us if you have any questions.



READY TO EXPAND YOUR CLARUS COLLECTION?

Visit clarus.com/build to start your next project!